

How To Install WheelBands

Important: Do not install WheelBands if temperature is below 10°C. Do not store in temperatures above 50°C.

Note: Please cut 5mm off each end of the WheelBands base before installing.

1. Wash the wheels and allow to dry. Ensure all required parts and tools ready. Note: cutters or knife not included.
2. Use RimPro-Tec wipe to remove any residue or contaminants that may remain on the wheel rim. Note: x4 wipes included in white RimPro-Tec package. Use one per wheel.



3. Choose the location on the wheel rim that the WheelBand base will adhere to, making sure the entire surface of the rim is completely undamaged for the adhesive tape to be applied to.
4. Gently place one end of the WheelBands base onto the desired part of the wheel rim making sure to hold the rest of the WheelBands base away from the wheel to avoid accidental adhesion.



5. Carefully peel off backing from the tape in small sections at a time whilst applying to the wheel. Do not handle the sticky surface of the tape as this could potentially reduce the adhesion.
6. Follow the wheel contour whilst pressing the WheelBands base firmly in place to complete the circle.



7. Carefully mark the WheelBands base and cut to desired wheel size ensuring both ends are flush together. Ensure there are NO GAPS. Discard any excess WheelBands base when finished.
8. Using the fitting tool, press the WheelBands base onto the rim FIRMLY. Ensure the WheelBands base has fully adhered to the rim wheel.



9. Insert the WheelBands Inner into the WheelBands base. Cut it to the desired length, making sure the Inner join is on the opposite side of the rim, to the WheelBands base join.
10. Using the fitting tool, ensure the inner has 'clicked' into the WheelBands base.



The vehicle can be driven immediately once the WheelBands system is fully installed.

DO NOT wash wheels for 72 hours following WheelBands installation.